


HANDLE MOUNTING INSTRUCTIONS

- HOLD THE HANDLE
- ALIGN THE HANDLE WITH THE SYMMETRICAL PLANE OF THE PUMP





- HOLD THE HANDLE NEAR THE PLUG
- SLIDE THE HANDLE IN THE SHOWED DIRECTION
 The cylindrical part of the handle have to match the cylindrical stainless steel surface of the pump




INSERT THE RED CAP




PUSH THE HANDLE TO FIT THE CAP



HANDLE DISMANTLING INSTRUCTIONS





USE A FLATHEADED SCREWDRIVER TO LIFT AND REMOVE THE RED CUPS



PULL THE HANDLE IN THE SHOWED DIRECTION



